

DIRECTOR D50-8 LOUDSPEAKER







- 5 1/411 (133mm) Poly/Rubber Woofer
- 1" (25mm) Silk Pivoting Tweeter
- Butyl Rubber X-Wave™ Surround
- Tool-less Mounting Installation

SPECIFICATIONS


PRODUCT NAME D50-8

Cutout Diameter 5 7/8" (150mm) Speaker Diameter 6 3/4" (172mm)

Mounting Depth 3 1/2 (90mm)

Grille Diameter 7 3/16" (182mm)

Grille Depth 3/16" (5mm)



Please visit docs.originacoustics.com or scan this QR code using your smart device for the most up to date safety information and use instructions for this product.




*All warranties and warranty conditions are subject to change. Please refer to docs.originacoustics.com for the latest information.






The Speaker will arrive securely in its Bayonet Ring. Scan the QR Code on the reverse of this page for full instructions for this product.

REMOVAL OF SPEAKER FROM BAYONET RING




OPEN POSITION: PULL THE METAL LOCK TAB AWAY from the Bayonet Ring, before removing loudspeaker from Bayonet Ring.



With one hand on the ring & one hand on the speaker, **ONE QUARTER TURN COUNTER-CLOCKWISE** will release the Speaker from the Bayonet Ring.

SPEAKER INSTALLATION




Push the Zip-Clip™ rails inwards, just enough from the top, so they fit through the ceiling hole opening, then INSERT THE BAYONET RING INTO THE CUT-OUT hole within the ceiling surface.



2


Reach through and **PLACE 2 FINGERS ON THE GROOVES** of the Bayonet
Zip-Clip[™] to pull each Zip-Clip[™] down
the rail.




PULL DOWN on all 4 Bayonet Zip-Clips™ to lower them along the Bayonet rails.




Note: If the Bayonet Zip-Clips[™] need to be adjusted or removed, depress the metal tabs along the rail and push up.



After connecting wires, insert the Speaker into the Bayonet Ring, with the METAL LOCK TAB LIFTED AWAY FROM THE RING.



TWIST THE SPEAKER 15 ° CLOCKWISE, until the indicators on both the Bayonet Ring & the Speaker are aligned.



CLOSED POSITION: To finalize the installation, **PUSH THE METAL LOCK TAB TOWARDS** the Bayonet Ring.

Note: Grille may not sit flush until this Lock is properly engaged.